



SÉURA MIRRORS

Clock Instructions

Updating the time on your clock is simple using the included remote control. The clock's IR sensor is hidden within the mirror about 2" below the right corner of the clock display. Point the remote towards this sensor and follow the below steps to change the settings of your clock.

USING THE REMOTE

1. Press and hold the OK key on the remote. The hours digit(s) will start flashing.
2. Use the up/down arrow keys on the remote to set the hour. Press OK, the minutes digits will begin flashing.
3. Use the up/down arrows on the remote to set the minutes. Press OK, the display will read either 12 or 24.
4. Use the up/down arrow keys to set the clock to 12 or 24 hour format. Press OK, the display will read either auto or on.
5. Use the up/down arrow keys to set the clock to either auto display timeout or always on.
6. Use the up/down arrow keys to set the clock's display orientation with "UP" as a reference.

